



Maße (cm)	28	29	30	31	32	33	34	Checkliste
a) Bundbreite			38	39,5	41	42	43	Farbe
b) Bundhöhe			5,5	5	5,5	5,5	5,5	Nähte
c) Hüftbreite			46,5	48	48,5	49,5	51	
d) Hüfthöhe			109,5	110	110	112,5	112	Reißverschluss
e) Schritthöhe			84,5	85	83,5	85	84,5	Taschen
f) Beinbreite oben			30	30,5	30,5	31,5	32	Knöpfe/Nieten
g) Beinbreite unten			20	20,5	20,5	20,5	20,5	Ersatzteile
a)Bundbreite INCH			15	15,5	16	16,5	17	
Schritthöhe			27,8	28	29,5	29	29,5	
Maße (cm)	36	38	40	42	44	46	48	Hangtag
a) Bundbreite	46	49	51,5	52	56	57	60	Lable
b) Bundhöhe	5,2	5,2	5,2	5,4	5,3	5,5	5,5	Fähnchen
c) Hüftbreite	53	56	57,5	59	61,5	63,5	66,5	Sizelable
d) Hüfthöhe	113	115	115	116,5	116,5	116,5	121,7	Waschlable
e) Schritthöhe	85	85,5	84,5	85,5	85	84	86,5	Verpackung
f) Beinbreite oben	33	35	35	36,5	37,5	38,7	40	Kartonage
g) Beinbreite unten	21	22	22	23	23,5	24	24,5	Waschprobe
a)Bundbreite INCH	18	19,5	20,25	20,5	22	22,6	23,75	Artikelnamen
Schritthöhe	30,2	32	32,5	33,5	33,5	35	37,5	